



No. SP-E1

Service Procedure Rev. 0
Service Department
For: Programming Smart Lift
Issue Date: January 17, 2001
Reissue Date:

Programming Smart Lift

To program Smart Lift the following steps must be taken:

INCREMENTS

- TOUCH BUTTON <PROG>
- TOUCH BUTTON <INC 1 OR 2>
- HOLD UP OR DOWN BUTTON FOR LENGTH OF INCREMENT
- TOUCH BUTTON <PROG>

POSITION

- TOUCH BUTTON <PROG>
- TOUCH BUTTON <POS 1 OR 2>
- HOLD UP BUTTON TO RAISE LIFT TO POSITION
- TOUCH BUTTON <PROG>

Programming increments or positions overrides previous programs. Smartlift retains programmed settings even when unplugged.

Service Department
P.O. Box 1380
Portland, Maine 04104-1380
service@SouthworthProducts.com
Tel: (800) 743-1000
(207) 878-0700
Fax: (207) 797-4743

Caution: Before performing any service on a machine read and understand all safety instructions in the service manual. Manuals are available free of charge, if you do not have one please call the Customer Service Department at the toll free number above.